
3-5. Using the interior lights Interior lights list




Front interior lights (\rightarrow P. 361)

- Remote touch light (when the "POWER" switch is in ACCESSORY or ON mode)
- Rear interior light
- **5** Door courtesy lights
- 6 Scuff lights (if equipped)
- **7** Footwell lights
- **8** Outer foot lights


Interior lights

Front



- Turns the lights on/off linked to door positions
- Turns the lights on/off

Rear



- 11 Turns the light on
- Turns the light on/off linked to door positions

Personal lights



Turns the light on/off

n Illuminated entry system

The lights automatically turn on/off according to "POWER" switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are opened/closed.

n To prevent 12-volt battery discharge

If the interior lights remain on when the door is not fully closed and the interior light switch (door position on/ off) is on, the lights will go off automatically after 20 minutes.

n Customization

Settings (e.g. the time elapsed before the lights turn off) can be changed. (Customizable features \rightarrow P. 572)